


- Cinema Control

The home page of the cinema has some basic information and controls such as the state of the A/C, currently selected source and the volume controls.

To turn the projector on, you will need to navigate to the watch page as below.



Once on the watch page, press the **Projector power** button to start turning the system on.



A loading screen will appear telling you the system is warming up. While the system warms up, the lights will begin to dim, and the introduction will play.

Once done, you will be able to select your desired source and use the control buttons.

Netflix and Blu-ray sources are both from the Blu-ray player. **The players location is in the Cinema AV room above the data rack. Inserting a disc once the system is on will automatically make the movie start.**

Selecting the HDMI source will allow you to connect a device to the HDMI point on the step near the seating in the middle of the cinema.

Selecting the TV source will display Free to Air TV, this will also hide some of the blue ray player options, and present the channel presets. There is also an individual power button for the Free to Air device if it is off for you to turn it back on.

Changing the channels or pausing or playing a movie can be done via the buttons at the top of the panel.

The blue bar at the bottom of the screen indicates volume level.

While the projector is on, manual control of the lighting is enabled which can be accessed through the "lights" menu button.

Once finished, please remember to turn off the system. The lights will automatically come back on.